

SAFETY INSTRUCTIONS

- For indoor use only.
- The power plug should always be within easy reach so that power could be turned off instantly in case there should be an emergency failure after installation.
- For your own safety, we recommend to form a drip loop with the connection cable to prevent any water running along the cable from intruding into the socket.
- Do not use the product if any part of connection cable or power adapter is damaged. The damaged parts must be replaced before using again. Use only original Chihiros parts.
- Children above the age of 8 or individuals with reduced physical, mental or sensory capacities or lack of experience or knowledge may be allowed to use the product, only provided they are supervised or have received instruction in the safe use of the product and therefore understand the risks involved. Do not allow children to play with this product. Do not allow children to clean or conduct user maintenance without supervision.
- Do not dispose of this product as normal household waste. Take it to your local refuse collection site.
- Never put the power adapter in or above of the aquarium cover.
- Do not open the power adapter, risk of electric shock.

SICHERHEITSHINWEISE

- Nur für den Innenbereich geeignet.
- Der Netzstecker sollte immer leicht erreichbar sein, damit im Notfall die Stromzufuhr sofort abgeschaltet werden kann.
- Bilden Sie zur eigenen Sicherheit eine „Tropfschleife“ mit dem Verbindungskabel, um zu verhindern, dass Wasser am Kabel entlang in die Steckdose läuft.
- Verwenden Sie das Produkt nicht, wenn Teile des Verbindungskabels oder Netzadapters beschädigt sind. Die beschädigten Teile müssen vor dem erneuten Gebrauch ersetzt werden. Verwenden Sie nur Originalteile von Chihiros.
- Kinder über 8 Jahre oder Personen mit eingeschränkten körperlichen, geistigen oder sensorischen Fähigkeiten oder mangelnder Erfahrung dürfen das Produkt nur unter Aufsicht oder nach Unterweisung im sicheren Gebrauch nutzen, um die Risiken zu verstehen. Lassen Sie Kinder nicht mit dem Produkt spielen oder es ohne Aufsicht reinigen oder warten.
- Entsorgen Sie dieses Produkt nicht als normalen Hausmüll. Bringen Sie es zur örtlichen Sammelstelle.
- Platzieren Sie den Netzadapter niemals im oder über dem Aquariendeckel.
- Öffnen Sie den Netzadapter nicht, da dies zu einem Stromschlag führen kann.