



Installation Manual




Components list



Pre-installation


TOOLS REQUIRED





HARDWARE INCLUDED

A Ø10 (x3) (x3) M8x90 (x3)	B (x1)	C (x1)	D (x1) (x1) (x1)
E (x3) ST3.5x30 (x12)	F (x1) Ø8 (x4) ST4.2x32 (x4)	I (x1) ST5.5x32 (x2)	
G (x3)	H (x2) ST4.8x50 (x4)	 (x1)	

Section drawing




Installation




Installation

3

A




(x1)



Ø10 (x3)




(x3)




M8x90 (x3)

G



(x3)



4



E




(x3)



ST3.5x30 (x12)




x3



Installation

5



H



(x2)



ST4.8x50 (x4)



6

B




(x1)

C




(x1)



Installation

7

F







(x1)



Ø8 (x4)







ST4.2x32 (x4)








Installation

8



Installation


9



Installation

10

D




(x1)



(x1)



(x1)



Installation

11

I



(x1)



ST5.5x32 (x2)

