

Montageanleitung

The diagram illustrates the assembly process for a cabinet unit. Key components and their dimensions are as follows:





- Main Cabinet Body:** Dimensions include 60.0cm (height), 110.0cm (width), 85.2cm (depth), and 57.2cm (internal width).
- Top Panel (A):** Dimensions include 60.0cm (height), 110.0cm (width), and 2.8cm (thickness).
- Side Panel (B):** Dimensions include 55.5cm (height) and 85.2cm (width).
- Front Panel (C):** Dimensions include 57.2cm (height) and 49.6cm (width).
- Internal Components:** Includes parts like D, E, F, G, H, I, J, K, L, M, N, O, P, Q, R, S.




The assembly steps shown include:

- Applying silicone sealant to the top panel (A).
- Inserting the top panel (A) into the main cabinet body.
- Attaching the side panel (B) to the main cabinet body.
- Attaching the front panel (C) to the main cabinet body.
- Installing internal components like D, E, F, G, H, I, J, K, L, M, N, O, P, Q, R, S.

Contact information for Service-Hotline:

Service-Hotline
01805-678101
0,14€ pro Minute
++49 für Österreich
Auslandstarif pro Minute
Service@jaka-bkl.de
Voor Nederland en België
00800-40119350
benelux@jaka-bkl.de

 →  →  ...		
 10x Nr. 98	 3x Nr. 523	 10x Nr. 76
 4x Nr. 502	 6x 6,3x13 Nr. 274	 14x Ø8x30 Nr. 80
 4x 4x13 Nr. 332	 2x Nr. 371	 2x Ø5x30 Nr. 81



Ersatzteile/Spare parts/pièces de rechange/Reserveonderdelen/Piezas de recambio/Ricambi/Зачастные части/Części zamienne/potlakarészek/Náhradní části/Nadomesti dell'vaarosaar/reservdealar/náhradné diely/Utilizati piese de schimb/Vedek parçalar

- [illegible]

