



Einhell

PROFESSIONAL



Top-handled Cordless Chain Saw

FORTEXXA 18/20 TH

Item No.: 4600020

Ident No.: 21011

Bar Code: 4006825663099

The Einhell handheld cordless chainsaw FORTEXXA 18/20 is a member of the Power X-Change family. The chainsaw is driven by a brushless electric motor, is equipped with an OREGON quality blade and chain and has a tool-free adjustable chain tension/change. The chain catcher, the kickback protection with instant chain brake and tip guard ensure safety and the automatic chain lubrication via the large oil filling opening for care. The claw stop is made of metal, the ergonomic handle is equipped with softgrip. **WARNING:** This chainsaw may only be used by qualified tree surgeons. Delivery does not include a battery (2.5 Ah recommended) or charger.

Features & Benefits

- Member of the Power X-Change family, 1x18V batteries necessary
- Einhell Brushless Motor
- High-quality chain and bar from OREGON
- Ideal for trimming and tree care
- Tip guard for prevention of kickback
- Kickback protection with instant chain brake
- Toolless chain tensioning and changing
- Handy, light and ergonomic
- Sturdy stop claws made of metal
- Big filler opening
- Automatic chain lubrication
- Chain catcher
- Top-handled chainsaw for fully trained tree care personnel
- Recommendation for optimum results: 2.5 Ah rechargeable battery
- Supplied without battery and charger (available separately)



Technical Data

- | | |
|-----------------------|--------|
| - Sword length | 200 mm |
| - Max. cutting length | 140 mm |
| - Chain cutting speed | 7 m/s |
| - Oil tank capacity | 75 mL |

Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight (kg) | 2.5 |
| - Gross weight (kg) | 3.5 |
| - Dimensions single packaging | 290 x 250 x 210 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight of export carton | 14.7 kg |
| - Dimensions export carton | 510 x 305 x 445 mm |
| - Container quantity (20"/40"/40"HC) | 1640 3360 |



Available as special accessories



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



Ersatzschwert 20cm 1,1
Chain Saw Accessory
Item No.: 4500194
Bar Code: 4006825664560
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



Ersatzkette 20cm 1,1 33T 3/8
Chain Saw Accessory
Item No.: 4500193
Bar Code: 4006825664577
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times



sawing¹
(pieces)

One Battery for All	
1.5 Ah	60
2.0 Ah	80
2.5 Ah	100
3.0 Ah	120
4.0 Ah	160
5.2 Ah	210
6.0 Ah	240
8.0 Ah	320

For best performance select a battery with at least 2.5 Ah

Test setup:

1) wood - scantling 70x70 mm