

For cleaning/disinfection of mask and filter, our recommendation is as follows:

1. Remove the pre-filter holder with the pre-filter from the particle filter.
2. Remove the particle filter from the mask.
3. Place the mask, particle filter, pre-filter, pre-filter holder in 70% Isopropyl alcohol or 60% ethyl alcohol / ethanol
4. The parts must be completely immersed in the ethanol for at least five minutes.
5. Lift out the parts (wear protective gloves). Shake out the ethanol.
6. Let the parts air dry for at least one hour before next use.
7. Check that the mask, particle filter, pre-filter and pre-filter holder are undamaged.

This disinfection procedure can be done as often as necessary.

- Change the pre-filter SR 221 at least every 7 days.
- Change particle filter SR 510 (P3) after 18 months or sooner if there is any concern regarding physical damage, hygiene (dirt/soil) or increased breathing resistance.

Sundström Safety AB

Huvudkontor/Head office: Stockholmsvägen 33 • S-181 33 Lidingö • Sweden • Tel: +46-(0)10 484 87 00 •

Fabrik/Factory: Västergatan 4 • S-341 50 Lagan • Sweden • Tel: +46-(0)10 484 87 00

Styrelsens säte:/Reg. Office: Lidingö • Org nr:/Reg No: 556147761201