


























TYPE T090-05


- (D) Montageanleitung
 - (GB) Assembly Instructions
 - (F) Instructions de montage
 - (I) Istruzioni di montaggio
 - (E) Instrucciones de montaje
 - (H) Szerelési utasítás
 - (NL) Montageaanwijzing
- © Copyright by PMA 07/14

852160







C...




C1




C2




C1 ⚡




C3




C4




C5





C6




C7 ⚡



C8



H	H ₁	L	L ₁	N
607	420	400	250	50
775	588	450	300	50
1217	1008	500	350	50
1469	1260	550	400	50
1856	1680	600	450	50
		750	600	50



- If a colored radiator is dirty due to transport, warehousing or installation, the surface of the radiator should be cleaned with cold or luke warm water. For persistent marks, a neutral or low alkaline cleaner can be used.
- Further cleaning can be achieved by using soft, non-abrasive cloths or rags.
- The surface temperature of the radiator must not be higher than 25 °C during the cleaning process.
- The maximum temperature for the detergent is 25 °C. Do not use steam jet appliances.
- Do not use scraping or abrasive devices. Only use soft cloths for cleaning. Vigorous rubbing is to be avoided.
- Do not use acid or alkaline detergents or wetting agents.
- Do not use organic dissolving agents containing ester, ketone, alcohol, aromatics, glycol ether, halogenated hydrocarbons or other similar products.
- Do not use detergents with unknown compounds.
- Rinse with clear, cold water immediately after cleaning.